

For dependable service, it is of utmost importance that instructions given below are followed for selection, inspection, installation, commissioning, operation and maintenance.

Selection:

- Refer Table A, B, C and D for recommended selection of starters.
- Table A: kW/HP rating, thermal overload relay range & fuse rating.
- Table B: Coil voltage
- Table C: Relay range codes.
- Table D: Max full load currents for different types of motors.

Inspection:

- Ensure that the relay range and coil voltage are as per your requirement.
- Inspect interior for breakage.
- If you find a serious defect, do not use the product but have it checked by an authorized Siemens dealer or an electrician.

Installation:

- Mount the starter in an enclosure and the enclosure on a vertical rigid surface free from vibration. The drilling template is enclosed for convenience. Refer Fig.1 for mounting dimensions and Fig.2 for permissible displacement from vertical plane.
- The enclosure should not allow ingress of dust, dirt or contamination.
- Connect the incoming and outgoing cables as follows
 - Select the correct size of cables from the table
- Connect line & mo exactly as per
 - diagram. Terminal screws

Tightenin

80-11



90

16.5.16.5

ø5.1

*80

Fig. 2 : Maximum permissible displacement from vertical plane

Commissioning:

Caution:

- During commissioning or maintenance always ensure that the main supply is disconnected by switching off the main switch.
- If the relay trips even when set at the rated motor current the suitability of the starter/relay for the particular application should be checked with the nearest Siemens office.
- Setting of 'Auto/hand reset' mode (Ref.Fig.3)
- In the delivered condition, the relay is set in H=Hand (manual) resetting mode. To change from H=Hand (manual)



H - Hand Reset A - Auto Reset

Fig. 3 : Relay Front View

4

resetting to A=Automatic (self) mode, press and turn the Blue button on the relay counter clockwise from H to A.

Procedure for setting the overlaod relay :

For closer protection, set the overload relay to actual current as measured by an ammeter.

In the absence of an ammeter, follow the procedure given below:-

- Set the relay to rated current mentioned on the motor name plate.
- Press the 'ON' button of the starter or the green buttor of the contactor to start the motor and wait till it reaches to normal speedend let it run for approximately 30 minutes on full load. The gradual of reduce the relay setting till it trips. Set the leavest a vlightly higher value than this setting.
 Allow the reset time of approximately 4 min before pressing the blue button of the relay to reset in HR model or the relay resets on this own after approx 4 minutes after it trips (in case the relay is set in Set in Set).

- Restart the motor. If the relay does not trip, consider it to be properly set. If it trips, set it at a little higher value than before and recheck.
- Overload relay characteristics shown in fig. 4 can be used to estimate the average tripping time at different puttines of
- the Ser current. Operating Characteristics

The given domacteristicativity 4) are average values of all the ranges and sizes of thimetal relates and are many thrended to hidizate the inverse time current characteristics of the same. The impung times shown are for relative starting from the cold state. At operating temperatures (heated at rated outrent) these are reduced to as our 25% of the value obtained from the entracteristics.

Operation:

 For starting the motor, install 'ON' push button (Green)contact element (NO) combination on enclosure cover and wire-up as shown in the wiring diagram. Press Green push button to start the motor. For stopping the motor, install 'OFF' push button (Red) contact element (NC) combination on enclosure cover and wire-up as shown in the wring diagram. Press Red push button to stop the motor.

For reseting the relay from panel door, use accessoryresseting cord with holder or reset funnel. (refer spares/ accessories list for ordering).

- In case you want the starter to be in 'Self-Reset'mode, the blue knob on the relay is to be pressed and rotated in the anti-clockwise direction, so that it comes in position 'A' and its edge is flush with the surface. In this mode even if the relay trips on overload, it will be automatically reset in a maximum of 4 minutes. The motor can be restarted only after the relay is reset.
- In hand reset mode for resetting, press button marked 'R' if the relay has tripped due to overload (use resetting cord with holder). In this case the motor can be restarted only after you reset the relay. Allow a minimum time of 4 minutes, before resetting it.



Note :

It is recommended that relay be set in the 'HR' (hand reset) mode in case of applications involving maintained 'ON' command e.g.use of autoswitch or float switch, etc. in order to avoid damage to the starter/motor.

Maintenance:

Switch off the starter and disconnect the main supply by switching off the main switch before doing any maintenance.

- Keep the interior dust free.
- Re-tighten the terminal screws from time to time.
- No maintenance is needed for overload relay. Please do not open the relay.
- Blackening of silver/alloyed contacts does not affect operational life. If necessary, clean the contacts of contactor with CRC 2-26.
 Remove the globules with a scrapper or a screw-driver with minimal force. Under no circumstances should the contacts be filed or dressed as it will reduce the electrical life drastically.

- If the contactor hums, clean the magnet pole with a soft cloth/CRC2-26/Chamois leather/ size 00 emry paper if found rusty.
- Replace contacts of the contactor if they are severely pitted or when only 40% of the original contact tip remains.

For details of contactor maintenance refer to our 'Guide to Contactor Installation & Maintenance'.

- Replacement of Arc Chamber:
- Remove the existing arc chamber as shown in (<u>F</u>

ment of overload

- Replace it by a new chamber (refer the for item no.)
- Ensure that he arc

is flush

bod

iii. Lift the overload relay vertically upwards to disengage its hook (Fig.6) from the slot of the bracket mounted on the base plate.

iv. Pull the overload relay away from contactor and in outward direction.

Select the overload relay of proper range by referring to table 4 and sparse list

Fig. 5 : Removal of arc chamber

er range by referring to A and spares list. he relay either in thand to r Auto reset mode

iii. Connect the relay terminals (L1 L2 L3) to the contactor termina s(N,T2 T3).

iv. Ensure that the relay hook (Fit.6-)) is engaged in the slot of the relay mounting bracket (Fig.6-2) and slide the relay inwards till the cover is flush with contactor ribs.(Fig.6-3)

v. Tighten the contactor terminal screws.

vi.Reconnect the disconnected relay wires and check the correctness of the starter wiring.



Fig. 6 : Contactor-Birelay Connection

- 1. Hook for relay engagement
- 2. Relay mounting bracket
- 3. Contactor ribs flush with relay edge.

- Replacement of the Main **Contacts:** (Fig.7 & 8)
- Remove the arc chamber. (Fig.5)
- Remove and inspect the contacts.
- When contact tips get eroded and base material is seen, refer spares list to replace contacts.
- Put back the Arc Chamber.

4

- Replacement of Coil: (Fig.9)
- Disconnect all the wires connected to the contactor. Disconnect the relay from the contactor and remove the contactor from the base plate by loosening the mounting screws.
- Turn the contactor upside down, unscrew the bottom cover and remove it.
- Ensure that the new coil is of proper voltage. (Table B).
- Ensure all springs are placed at proper location.
- Put back the bottom cover.

Fig. 8(A) contacts

Fig. 7 : Fixed/moving, main/auxiliary contacts inspection.

- 1, 2, 3 : Main contacts
- : Auxiliary contacts 4
- 5, 7 : Fixed contacts
- : Moving contacts 6
- 10



Table A : Selection Table for RAJA Starter in open execution

Spares List

Voltage

200-400 V

130-230V

Code

В

Ρ W Μ

1) RAJA DOL Starter for Monobloc pumps

Rating	g for 4P,		Delay	Back-u	p Fuse	Recomm-
415\	/, 3Ph,	Turne	Pango	Rat	ing	ended
50hz	Motor	туре		HRC fuse	Rewir-	Cu cable
HP#	kW		300050	Rating (A)	able	size (mm²)
5	3.7	3TW4200-0A*74	6.3-10	25	21 SWG	1.5
-	-	3TW4200-0A*75	8-12.5	25	19 SWG	1.5
7.5	5.5	3TW4200-0A*77	10-16	32	18 SWG	2.5
10	7.5	3TW4200-0A*78	12.5-20	32	18 SWG	4

2) RAJA DOL Starter for Submersible Pumps

ĺ	Rating	g for 4P,			Polov	Back-u	p Fuse	Recomm-	XX	C	Co
	415V	/, 3Ph,		Tupo	Rango	Rat	ing	ended	75 /	X	
ļ	50hz	Motor		туре		HRC fuse	Rewir-	Cu cabie		6	Cov
	HP#	kW			300050	Rating (A)	able	size (mm)		7	Aux
	5	3.7	зтw	4200-0A*75	8-12.5	25	19 SWO	1.5	b	8	
	7.5	5.5	зтw	4200-0A*77	10-16	32	18 SWC	2.5	h		7
	* Ente # Whil not e	er code fe le select exceede	or coil ing pl. d.	voltage (Table E ensure that rat	3) ed AC3 cu	urrent rating	(20)) of th	ne starter is) (đ		e B
						\mathbf{x}			0		/oltag
						\mathcal{O}		, V	,	2	.00-40
					$\dot{\mathbf{o}}$		$^{\circ}$	·.C	Š	1	30-23
						<i>г</i> •				4	15 V
						~	· (\sim		2	20 V
						Q		<u>U</u>			
	12						\checkmark				
							-				

Sr. No.	Description	Oldeř No.
1	Contactor	BTW0 290-0A * 51 (Refer Table B for*)
2	Birelay	3UW50 02 - ** (ReferTable C for **)
Q	Main contact hit (Each set comprises of 6 Fixed Contacts and 3 (Moving Contacts)	3TX0 200-0YA0
0	Connect Kit - Single Fole Fach set comprises of 2 fixed contacts and 1 moving contact.	3TX0 200-0YA1
C	Colt of	3TX 203-0Y*6 (ReferTable B for *)
6	Cover (Arc chamber)	3TX0 202-0YA0
7	Aux fixed contact	3TX0 200-1YB0
8	Aux. moving contact	3TX0 200-1YC0

Table C

Relay Range	Code for
6.3 - 10	1J
8 - 12.5	1K
10 - 16	2A
12.5 - 20	2B

Accessories List

1

Wiring Diagrams:





Notes

____|

Kanchan 253 e e kanchananand. com Kanchan 253 e e kanchananand. com Kanchan 253 e e kanchananan e kanchanan e kanchan e kancha

19





___ |

Spares List

	Description	Order No.		
1	Contactor	3TW0 290-0A * 51 (ReferTable B for*)	1ª	
2	Birelay	3UW50 02 - ** (ReferTable C for **)	1	
3	Main contact kit (Each set comprises of 6 Fixed Contacts and 3 Moving Contacts)	3TX0 200-0YA0		
4	Contact Kit - Single Pole	3TX0 200-0YA1	S	Nse plier
5	Coil	3TX 203-0Y*6 (ReferTable B for *)	0	
6	Cover (Arc chamber)	3TX0 202-0YA0		
7	Aux. fixed contact	3TX0 200-1YB0		
8	Aux. moving contact	3TX0 200-1YC0		
9	'ON' SPA	3TX0 204-1YA0	Fg. (IN) Replacement of	moving contacts Fig. 11(B) Replacement of fixed co
10	'OFF' SPA	3TX0 204-1YB0		
11	'Reset' SPA	3TX0 204 - 1YR0		
12	Contact Holder	3TX0 200-0YD0		
13	'ON/OFF' contact Element	3SX1 551 - 1 A	hr N	
14	Switch for HSD starter	3LA0 201 - 47B		a constant
14 ble C	Switch for HSD starter	JLAO 204-448		
14 ble C Relay	Switch for HSD starter	JLAO 20-4/B		
14 Die C Relay 0.63	Switch for HSD starter	3LAO 201-4/B		
14 ble C Relay 0.63 1 1.6	Switch for HSD starter Range Code for - 1 0J - 1.6 1A - 2.5 1C	3LAO 20-4/B		
14 ble C Relay 0.63 1 1.6 2	Switch for HSD starter Range Code for - 1 0.J - 1.6 1.A - 2.5 1.C - 3.2 1.D			
14 ble C 0.63 1 1.6 2 3.2	Switch for HSD starter Range Code for - 1 0J - 1.6 1A - 2.5 1C - 3.2 1D - 5 1F	3LA0 207-478		
14 ble C <u>Relay</u> 0.63 1 1.6 2 3.2 4	Switch for HSD starter Range Code for - 1 0J - 1.6 1A - 2.5 1C - 3.2 1D - 5 1F - 6.3 1G	3LA0 207-478		
14 ble C Relay 0.63 1 1.6 2 3.2 4 6.3 2	Switch for HSD starter Range Code for - 1 0J - 1.6 1A - 2.5 1C - 3.2 1D - 5 1F - 6.3 1G - 10 1J	3LA0 20-478	Fig. 12 Replacement of Col 1 : Bottom Cover	6 : Return Spring
14 ble C Relay 0.63 1 1.6 2 3.2 4 6.3 8 10	Switch for HSD starter Range Code for - 1 0J - 1.6 1A - 2.5 1C - 3.2 1D - 6 1F - 6.3 1G - 12.5 1K - 12.5 1K	3LA0 20-478	Fig. 12 Replacement of Co 1 : Bottom Cover 2 : Liner for shock absorp 3 : Eived Magnet	A 6 : Return Spring tion 7 : Coll 8 : Contactor bousing along with moving





Operation

ON/OFF Operation

Switch ON' the starter by pressing the green push button marked 'l') Fig.16-1) on the starter cover.

Switch 'OFF' the starter by pressing the red push button (marked 'O') (fig. 6-2) on the starter cover.

- Reset Operation
- If the overload relay trips, it resets automatically.
 (*Allow a reset time of approx. 4 min.)
- It is recommended that the DOL Starter (Self reset type) is not to be used in applications involving maintained 'ON' command. In such applications hand reset type of starter is recommended.
 - iv. Pull the overload relay away from contactor and in outward direction.

Table D

later	Poting	Max.	Full Load Current	(Amp)			
P	kW	3 Ph, 415V, 4P Squirrel Cage IS 8789 : 1996 Table 4	3 Ph, 415V, 2P Submersible Motor IS 9283 : 1995 Table 2	1 Ph, 240V CSIR or Split-Phase IS 996 : 1979 Table 9			· more
.33	0.25	_	_	3.8			
0.5	0.37	1.4	-	6		S con	
0.75	0.55	1.7	-	7		O_AOH	
1	0.75	2.2	-	7			
1.5	1.1	2.9	3.25	13			
2	1.5	3.8	4.5	18	X		-CG
3	2.2	5.1	6.5	-	\mathcal{O}^{i}		LUL Base
5	3.7	8.1	10				
7.5	5.5	11.4	14.5		al		
7.5 10	5.5 7.5	11.4	14.5 19.5		. Sh	Fig. 3 A.B. Connection of outgoing and incom	ning cable, using cable gland.
7.5 10 12.5	5.5 7.5 9.3	11.4 15.4 19.5	14.5 19.5 25		، برن ک	Fig. 3 A.B. Connection of outgoing and incom outgoing cable connections. (fig. 2)	ning cable, using cable gland. (Terminal Screws : M4, Stripped Length : 10 mr
7.5 10 12.5 15	5.5 7.5 9.3 11	11.4 15.4 19.5 23	14.5 19.5 25 29			Fig. 3 A.B. Connection of outgoing and incom outgoing cable connections. (fig. 21 Connect incoming and	ing cable, using cable gland. (Terminal Screws : M4, Stripped Length : 10 mi • Set the overload relay s
 7.5 10 12.5 15 20 	5.5 7.5 9.3 11 15	11.4 15.4 19.5 23 32	14.5 19.5 25 29 39			Fig. 3 A.B. Connection of outgoing and incom outgoing cable connections. (fig. 2) Connect incoming and outgoing cables as follows : (fig. 3)	 ing cable, using cable gland. (Terminal Screws : M4, Stripped Length : 10 mr Set the overload relay s (fig. 4A-4) using proper screw driver as per the
7.5 10 12.5 15 20 25	5.5 7.5 9.3 11 15 18.5	11.4 15.4 19.5 23 32 38.5	14.5 19.5 25 29 39			Fig. 3 A.B. Connection of outgoing and incom outgoing cable connections. (fig. 2) Connect incoming and outgoing cables as follows : (fig. 3) - Select correct size of cable from Table-A (max_cable size	 (Terminal Screws : M4, Stripped Length : 10 mr Set the overload relay s (fig. 4A-4) using proper screw driver as per the procedure given below (fig. 5)
7.5 10 12.5 15 20 25 e : The	5.5 7.5 9.3 11 15 18.5 above table <i>g</i>	11.4 15.4 19.5 23 32 38.5 gives the max. full	14.5 19.5 25 29 39 10ad arcentor varia			 Fig. 3 A.B. Connection of outgoing and incomoutgoing cable connections. (fig. 2) Connect incoming and outgoing cables as follows : (fig. 3) Select correct size of cable from Table-A. (max. cable size allowed is 4 mm²) 	 ing cable, using cable gland. (Terminal Screws : M4, Stripped Length : 10 mr Set the overload relay s (fig. 4A-4) using proper screw driver as per the procedure given below (fig. 5) Set the relay to rated cu
7.5 10 12.5 15 20 25 e : The con con app	5.5 7.5 9.3 11 15 18.5 above table s immonly used. junction with ropriate relay	11.4 15.4 19.5 23 32 38.5 gives the max. full It is recommender motor name plate range.	14.5 19.5 25 29 39 load correspondence d that the above tab rate before selection	- - - - - - - - - - - - - - - - - - -		 Fig. 3 A.B. Connection of outgoing and incomoutgoing cable connections. (fig. 2) Connect incoming and outgoing cables as follows : (fig. 3) Select correct size of cable from Table-A. (max. cable size allowed is 4 mm²) Remove approx. 10 mm of insulation. 	 ining cable, using cable gland. (Terminal Screws : M4, Stripped Length : 10 mr Set the overload relay s (fig. 4A-4) using proper screw driver as per the procedure given below (fig. 5) Set the relay to rated cu mentioned on motor na plate.
7.5 10 12.5 15 20 25 e : The con con app	5.5 7.5 9.3 11 15 18.5 above table entronly used. junction with ropriate relay	11.4 15.4 19.5 23 32 38.5 gives the max. full It is recommender motor name plate range.	14.5 19.5 25 29 39 Ioad oncentror varied that the above tab onth before selecting the selecting of the selecting	- - - - - - - - - - - - - - - - - - -		 Fig. 3 A.B. Connection of outgoing and incomoutgoing cable connections. (fig. 2) Connect incoming and outgoing cables as follows : (fig. 3) Select correct size of cable from Table-A. (max. cable size allowed is 4 mm²) Remove approx. 10 mm of insulation. Pass the cable through proper cable gland to avoid ingress of material. 	 ining cable, using cable gland. (Terminal Screws : M4, Stripped Length : 10 mr Set the overload relay s (fig. 4A-4) using proper screw driver as per the procedure given below (fig. 5) Set the relay to rated cumentioned on motor na plate. Press green button of th contactor (fig. 4B-7) to s the motor and wait till it
7.5 10 12.5 15 20 25 ≥ : The con app	5.5 7.5 9.3 11 15 18.5 above table r nmonly used. junction with ropriate relay	11.4 15.4 19.5 23 32 38.5 gives the max. full It is recommender motor name plate range.	14.5 19.5 25 29 39 load orden for varied d that the above tab of the before selection	- - - - - - - - - - - - - - - - - - -		 Fig. 3 A.B. Connection of outgoing and incomoutgoing cable connections. (fig. 2) Connect incoming and outgoing cables as follows : (fig. 3) Select correct size of cable from Table-A. (max. cable size allowed is 4 mm²) Remove approx. 10 mm of insulation. Pass the cable through proper cable gland to avoid ingress of material. Connect the cables and tighten the screws firmly. 	 ining cable, using cable gland. (Terminal Screws : M4, Stripped Length : 10 mr Set the overload relay s (fig. 4A-4) using proper screw driver as per the procedure given below (fig. 5) Set the relay to rated cumentioned on motor na plate. Press green button of th contactor (fig. 4B-7) to s the motor and wait till it reaches to normal spee Reduce the relay setting trips.



