
SIEMENS



■ Description

Siemens BS type HRC fuse holders provide a simpler safe range designed to accomodate the compact range of offset blade tag fuse links. The combination offers significant savings in volume and cost as well as a reduction in fitting time and power loss. The 20A fuse holder (Type 3NW20NNSF) is suitable for fuse links rated upto 20A (3NWNS range). The 32A fuse holder (type 3NW32NNSF) is suitable for fuse links above 20A and upto 32A (type 3NWNS range).

Standards

Siemens HRC fuse holders conform fully to the requirements of national and international standards, IS 9224-1979/IS 13703-1993, IEC-269 and BS88 to accomodate blade tag fuse links to BS88: Part 1 & 2-1988, IS 13703: Part 1 & 2-1993, IEC 269: (1986) and 269-2-1

■ Applications

acts. This fit. Siemens HRC fuse holders along with BS fuse links provide a safe and a easy method of protecting a wide range of electrical equipments such as lighting, heating, motor and control equipment circuits and offer significant saving on volume, cost time and power

■ Features

Siemens fuse holders has been successfully tested for short circuit breaking test of 80KA with a Siemens blade tag fuse link at CPRI.

The fuse holder incorporates a unique free fitting of fuse links and locks the fuse link in position ensuring safe insertion and withdrawal from the base. The resulting direct contact between fuse link blades and the plated base contacts provides low watt loss and increased reliability.

The fuse carriers are fitted with a cam for ease




of removal from the fuse base. Further the cam ensures an improved contact pressure between fuse carrier and fuse base contacts, with a corresponding enhanced electrical performance level. This unique design overcomes a major problem of all existing fuse holders manufactured in the

operation by a screw driver is enough. Time consuming operations like fixing screws at the time of installation or removing them at the time of replacement are not

andard oolled direct 35 mm. ounting feature.

s HRC fuse se an be installed DIN rails by a simple anap action. Similarly for removal a simple




Selection Table

Fuse holder type	Current Rating Amps	Max. Volts type AC/DC	Fuse link type
3NW 20NNSF	20	550	3NW NS2 3NW NS4 3NW NS6 3NW NS10 3NW NS16 3NW NS20
3NW 32NNSF	32	550	3NW NS25 3NW NS32

Technical Details

Rating Amps.	MLFB	Max. Cable (A1) mm²	Fuse link type	Dimensions
20	3NW 20NNSF	4	F1 of IS 13703	As per drawing
32	3NW 32NNSF	10	(3NWNS)	

3NW fuse holders dimensions (mm)



Registered & Corporate Office:

130 Pandurang Budhkar Marg, Worli, Mumbai 4000018 ☎+91 22 4934080, 4934161 Fax +91 22 4950552

Sales Offices:

 Ahmedabad 380009 1st Floor, Shanti Chamber Terapanth Marg, Navrang 2 +91 79 6581803 6588 Fax +91 79 658610

Bangalore 5612 No. 84, Keonics Ele ₩±91 80 8521122-29 Fax +91 80 8521180

 Calcutta 700078 43 Shanti Palli, Eastern Metropolitan Bypass 2 +91 33 4421134, 4421135 Fax +91 33 4421137

 Chennai 600034 144, Mahatma Gandhi Road 22+91 44 823 1826/1124 Fax +91 44 825 5731/5728

 Coimbatore 641018 No 29 First Floor, Addis Street, Grey Town **2**+91 422 380908, 380270 Fax -91 422 380271

 Mumbai 400018 130 Pandurang Budhkar Marg, Worli **2**+91 22 4931352-57, 4987000-02 Fax +91 22 4950552

 New Delhi 110002 4A, Ring Road, I.P. Estate ★91 11 3738589, 3738594 Fax +91 11 3314178

Pune 4110014

☎+91 240 38

ant Vihar, 1205/2/6 nagar 2491 20 555 55 Fax +91 20-1

Secun era ad 500025 9-1-87/119/2 st /loor, St. John's ☎+91 40 7702-552, 7704544 Fax +91 40 7702951

esident Sales Engine Aurangabad 43100 a, Navyug Golony, Pad

Bhopal 462016 10, Ranut Apas Shalimar Enclave lony Extn. 5 555956/7 91 755 557295

Bhubaneshwar 751007 85, Shahidnagar, Orissa **2**+91 674 522839

Baroda 390009 43, Vivekanand Society Makarpura Road, Opp. ONGC Office **2**+91 0265 658213

 Bokaro 827001 110, 1st floor, Co-operative Colony Bokaro Steel City **☎**+91 6542 46185

 Cochin 682016 Preethi Building, 1st floor M G Road, Ernakulam **☎+**91 484 380201, 380506 Fax +91 484 371564

Durg 491001

258, Padmanabhpur, Madhya Pradesh **☎**+91 788 320337

Durgapur 713216 A-32, Abanindranath Bithi, 1st Floor, Non-company City Centre, W. B. ☎/Fax +91 6542 46185

Guwahati 781019 C/o Mr. Mahendranath Chamua, Kahilipara, Kalyaninagar, Assam **2**+91 361 620332

 Hardwar 249403 H-18, Shivalik Nagar Phase II, B.H.E.L. Ranipur ☎/Fax +91 133 440767

 Indore 452001 78, Anand Nagar, Chitawad Road ☎/Fax +91 731 400735

 Jainur 302017 B-310, Malviya Nagar, Hari Marg, Rajasthan ☎/Fax +91 141 521967

 Jallandhar 144001 958-C. Urban Estates Phase II Jallandhar City ☎/Fax +91 181 463201

 Kanpur 208002 Flat No 3 House No 3/254 Classic Apartment, Vishnupuri, U.P. ☎/Fax +91 512 561773

 Kolhapur 416008 Deo Datta, Plot No. 9 Ideal Co-op. Hsg. Society, Sagarmal ☎/Fax +91 231 652209

Lucknow C-447, Indra Nagar ☎/Fax +91 522 351773 Ludhiana 141001

67, Defence Colony (Shamsher Nagar) **BRS Nagar** 2491 161 457199

 Madurai 625003 E-212, Santhanam Road, T.V.S. Nagar 2 +91 452 673388

 Nagar 440 025 F1 Gulmohar Apartment, 1st Floor Opp. Sonegaon Police Station, Warda Road ☎/Fax +91 712 260697

 Nashik 422002 Flat No 3, Bldg No 63, Santoshi Building Ushakiran Society, Triambak Road ☎/Fax +91 253 311029

Panchkula 134401 902, Sector 16 ☎+91 172 578902, 666602 Fax + 91 172 578903

Rourkela 769006 Post Box No 51, F/1 Sector 2 ★+91 661 546504, 542897 Fax +91 661 542897

 Shaktinagar 231222 Panchwati Guest House Kota Basti, Uttar Pradesh **2**+91 544 638167 Fax +91 544 632518

Vadodara 390009 130 Vijay Nagar, Tarsali **☎**+91 265 647509

 Vishakhapatnam 530002 SF-2 Door No. 57-11-14/10 Mahalaxmi Enclave, Maddilapalem (Isakathota) Near Krishna College **2**+91 891 539601